


Running NMR with small sample volumes

- 1) Center your sample in the coil
- 2) Click on the lock/shim options icon: 
(see me if your username doesn't have access to this feature)
- 3) Type "topshim shigemi" in the Shim Program input
- 4) DO NOT change anything under ATM Controls!

